



Note:

- Sealant must be applied between head flashing and liner in VH and EH wind zones and SED wind pressures