

Note: When HomeRAB™ Pre-Cladding/ RAB™ Board is used flashing tape to be applied to the entire meterbox.

Timber Batten, Underlay for Texture Coating

jhl_axon24_t_029