1200mm wide soffits

Butt joint with 1 - 2 mm gap

12 mm edge distance

2400 mm long sheet

Bearers at 600mm centres

*50mm from corner

Fascia

Daubs of adhesive at 300mm centres

Hardie™ Groove Lining

Daubs of adhesive at 300mm centres

40 x 2.8mm Hardie™ Flex nails at 200mm centres

Double nails or screws 50mm apart to centre of sheet

Ribbon board

Soffit bearer

40 x 2.8mm Hardie™ Flex nails at 200mm centres

Note:
- Suitable for up to and including VH wind zone
- Do not nail within 5mm of groove

JamesHardie™

www.jameshardie.co.nz

Eaves and Soffit

Eaves Framing
Hardie™ Groove Lining nail/screw and adhesive fixing

January 2025
Scale: 1 : 20

Figure 15