



Notes:

- Hardie™ 14mm aluminium trimline joint, take care to ensure continuous seal is formed between panel and the trimline joint
- A James Hardie supplied 'Trimline Horizontal Jointer' flashing will be required over the butt joint of the Hardie™ 14mm aluminium trimline joint
- Site cut edges to be primed
- The flashing to be placed in the centre of the floor joists. Fix cavity battens into floor joists