

Note: Sealant must be installed between head flashing and window flange in VH and EH wind zones and SED pressures

jhl_wbrd_u_029 jhl_wbrd_ktaltd.rvt



Hardie™ Plank Weatherboard

September 2021 Scale: 1 : 2

On Timber Cavity Batten with Flexible Underlay ONE PIECE HEAD FLASHING WITH FACINGS